

PHILIPS

hue personal
wireless
lighting

Dimmer Switch



User manual
Notice d'emploi
Manual de usuario



Dimmer Switch
Gradateur
Interruptor





Wall Plate
Plaque murale
Placa de pared

On/Off button
Bouton Marche/Arrêt
Botón encendido/apagado



Setup button
Bouton de configuration
Botón configuración




1



www.philips-hue.com/connectproduct


2a > 3

2a




2b > 4

2b




3

> 8




!




hue
APP



4




5




6



7




click




on/off
Marche/Arrêt
encendido/apagado

hold



dim up/down
gradateur
atenuar

click



scene cycle
Prochaine scène
(d'éclairage)
Siguiente escena
(de luz)



Read
Lecture
Lectura




Relax
Détente
Relax




Concentrate
Concentration
Concentración




Energize
Stimulation
Energía




8a




8b




8c







1




2



3



4





www.philips-hue.com





Signify North America Corporation
400 Crossing Blvd, Suite 600
Bridgewater, NJ 08807, USA

Signify Canada Ltd./Signify Canada Ltée.
281 Hillmount Road,
Markham, ON, Canada L6C 2S3

Questions or Comments / Questions ou commentaires :
1-800-555-0050

Importado y/o distribuido en México por:

Signify Mexico S.A. De C.V.
Av. La Palma No. 6,
La Herradura, Huixquilucan,
Edo de México, C.P. 52784, México
RFC PME-620620-E84

Centro de contacto :
800-508-9000

www.philips-hue.com

© 2023 Signify Holding
All rights reserved

3222 639 06044
Last update: 02/2023