


Signify
I.B.R.S / C.C.R.I. Numero 10461
5600 VB Eindhoven, The
Netherlands

Service Hotline:00800-74454775 © 2023 Signify Holding

Dismantling Recommendation on Disposal at End of Life

Composition Explanation





Signify
I.B.R.S / C.C.R.I. Numero 10461
5600 VB Eindhoven, The
Netherlands
Service Hotline:00800-74454775
© 2023 Signify Holding

Recommendation on Disposal

• Plastic part: Reuse and Recycling

• Electrical part: Incineration and disposal

· Metal part: Recycling


Part list


Plastic part	Electrical part	Metal part
Housing	Light source	Screws
Diffuser	Driver module	
Mounting bracket	Solar panel	
Other small plastic part	Other small electrical part	Other small metal part
-Sensor lens		
-Connector		
-Driver box		
-Others		





Signify
I.B.R.S / C.C.R.I. Numero 10461
5600 VB Eindhoven, The
Netherlands
Service Hotline:00800-74454775
© 2023 Signify Holding

Light Source Replaceable description Non-user replaceable: a Old Light Source Disassembly Instruction













Battery Dismantling Instruction





Driver Dismantling Instruction











Signify
I.B.R.S / C.C.R.I. Numero 10461
5600 VB Eindhoven, The
Netherlands
Service Hotline:00800-74454775
© 2023 Signify Holding

b. New Light Source Assembly Instruction









New Battery Assembly Instruction

