










1. Dismantling:


a. Part list:

Plastic part	Electrical part	Metal part
Cover 	PCB 	Base 
Lens 	Wire 	Screws 
Other small plastic part: 	Other small electrical part 	Other small metal part
-Driver box 		
-Connector		
-Terminal block		
-Others		



Signify
I.B.R.S / C.C.R.I. Numero 10461
5600 VB Eindhoven, The
Netherlands
Service Hotline:00800-74454775
© 2021 Signify Holding


b. Dismantling:




2. Light Source Replaceable description

Non-user replaceable:

a. Old Light Source Disassembly Instruction



b. New Light Source Assembly Instruction:



Philips and the Philips shield Emblem are registered trademarks of Koninklijke Philips N.V